







Noremax Legs Mounting instructions

This is included:
Furniture leg adapter plate
Screws
Bolt
Furniture pads




NOTE! For safety reasons, make sure to always attach your storage unit to the wall.

NOREMAX

Pax- Side panel Mounting instructions

Place the side panel in position.
Note! The side is wider than the Ikea frame, to cover the thickness of the door front. Please control thickness of door front. The side should protrude so it's in line with door fronts.

Use mounting screws from the inside of the frame to attach the side panel. 8-10 screws are enough.
IMPORTANT! Do not screw through the thickness of the whole side.
See picture below as guideline



NOTE! For safety reasons, make sure to always attach your storage unit to the wall.

NOREMAX